

Color Change™ On-press Screen Opener

Environmentally Friendly • 100% Biodegradable • Non-Toxic and Non-Caustic

Quickly change colors on press or open clogged mesh areas during a run, saving valuable time and money. Color Change™ is non-aerosol and replaces harsh chemicals such as Methylene Chloride *without* the negative side-effects and offensive odor.

To Use:

- 1. Remove excess ink from screen.**
- 2. Pour or spray a small amount of Color Change™ on both sides of the screen.**
- 3. Work in with Franmar's White Biggee Pad or a nylon brush.**
- 4. Wipe both sides of screen with a damp shop towel. If cleaning the screen in a washout booth, spray clean with water.**
- 5. Use shop towel to wipe dry. Screen is now ready to re-tape and re-ink. If tape does not stick, wipe again with DAMP shop towel and allow to dry thoroughly.**

Color Change™ does not evaporate, a water rinse or cleaning with a damp shop towel is necessary to remove the oil residue.

- ✓ **Tip #1** Remember, less is better. Use small amount and you will immediately see the ink loosen.
- ✓ **Tip #2** Works great for cleaning ink smudges on backside of screen.
- ✓ **Tip #3** D-Grease™ can be used to wipe away any solvent residues.

SCREEN OPENER DIRECTIONS: *(replacement for aerosol screen opener)*

- 1. Spray small amount of Color Change™ on a shop towel.**
- 2. Wipe screen area clean.**

For friendly customer service call us toll free

800-538-5069

7am - 5:30 pm Mon - Thurs. Friday 7am - 5:00 pm CT

or visit our website: www.franmar.com



FRANMAR
Chemical®

